



This form can be completed using Adobe Acrobat.

### SHORT TERM Radon Gas INSTRUCTIONS

48 - 96 Hour Exposure Period

Get Results at: <https://InspectUSA.com/results> (with serial # & site zip code)

#### DO NOT OPEN DEVICE UNTIL YOU ARE READY TO START TEST!

Instructions are provided to you with specific steps that must be followed. Inspect USA, National Safety Products, Accustar Labs, or any of its affiliates, cannot provide any warranty remedy to you for any claims, which arise due to the failure to follow instructions.

1. Check the expiration date on each device. Start your test before the expiration date or results are invalid.
2. When you are ready to start the test, remove the lid from the device. As soon as you remove the lid, the device is "ON" and the test has begun.
3. Write each device number along with your name, address, email address, test site address & zip code on the **INFORMATION FORM** below. **Write in the test BEGINNING date & time!** Also indicate the location, floor level & the name of room (ie. basement, living room, bedroom etc) where the device is being exposed. Be sure to print legibly so we can get your accurate results to you promptly.
4. **PLACE THE RADON DEVICE.** Device should be placed in the lowest level of the house that is regularly used for 8-10 hours per week. If making a follow-up measurement, the US EPA recommends placing a device on each level that is used for living space. Do **NOT** test in garage, porch, kitchen, closet, bathroom, furnace room, laundry room, root cellar, crawl space or sump. DO **NOT** place devices where they will be exposed to high humidity &/or noticeable drafts from open doors, windows, fireplace, heat/air conditioning vents etc. Place each device at least 3' from exterior doors or windows & at least 2' off the floor. If performing a duplicate test (typically for Real Estate Transactions), place 2 devices side by side 4" apart. Leave each device in place & undisturbed for 48-96 hours.
5. **END RADON TEST.** After 48 hours (and before 96 hours) securely replace the lid back on each device (if using canister, replace the vinyl tape where the base meets the lid. Do not cover device serial number with tape). Write the test ENDING date on the INFORMATION FORM below. **Make sure the INFORMATION FORM is complete and LEGIBLE.** If devices are exposed for less than 2 days or more than 4 days the results will be invalid. You will need to buy another kit & repeat the test.
6. Record the device number(s) for your reference and ability to retrieve results online. Online results are typically available within 24-48 hours of the lab receiving the device(s). **Get Results at: <https://InspectUSA.com/results> (with serial # & site zip code)**
7. Place the device(s) & information form in the mailing package. **Write your return address & seal the mailing package closed.**  
**Affix proper postage! Return IMMEDIATELY to: RADON LAB, 2 Saber Way, Ward Hill, MA 01835**  
We recommend getting DELIVERY CONFIRMATION

**Devices must be returned within 8 days of ending the test.**

If delivery of your kit is delayed more than 8 days or lost, we will not be responsible for invalid results or for a free replacement kit.

Reports are available online next business day (approx 4.30 eastern) after we receive your devices.

email: [results@InspectUSA.com](mailto:results@InspectUSA.com)

Get Results: <https://InspectUSA.com/results> (with serial # & site zip code)



**CUT HERE**

### INFORMATION FORM

**CUT HERE**



<b>Email Report To: (PRINT)</b>		<b>Test site address: (zip code needed for online results)</b>	
Company:		Name:	
Name:		Address:	
Address:		City, State, Zip	
City, State, Zip		<input type="checkbox"/> Check here if canisters were placed 4" apart	
eMail address:		<input type="checkbox"/> Check here if this test is a Post Mitigation test	
Tech name & Certification # (if required):			
Canister #:	Canister #:	Canister #:	
Floor level:	Floor level:	Floor level:	
Name of area:	Name of area:	Name of area:	
Date & Time Opened:	Date & Time Opened:	Date & Time Opened:	
Date & Time Closed:	Date & Time Closed:	Date & Time Closed:	

**Lab must receive within 8 days from closing the canister(s) or test is invalid.**

**Don't forget Postage!**